

# Mbsm.pro, Compressor, Embraco, aspera, ne6187z, 1/3 hp++, big, CSIR, HMBP, r134a, 230/1/50

written by Lilianne | 11 April 2022



Private Picture Copyright: WWW.MBSM.PRO

Mbsm.pro, Compressor, Embraco, aspera, ne6187z, 1/3 hp++, big, CSIR, HMBP, r134a, 230/1/50

---

**Mbsm.pro, Compressor,  
embraco, aspera, nj6226z,  
HBP-R134a, 220-240V/1/50Hz, 1  
HP++, displacement 34.38 cm<sup>3</sup>,  
LRA 31.0 A**

written by Lilianne | 11 April 2022



Private Picture Copyright: [WWW.MBSM.PRO](http://WWW.MBSM.PRO)

Mbsm.pro, Compressor, embraco, aspera, nj6226z, HBP-R134a,  
220-240V/1/50Hz, 1 HP++, displacement 34.38 cm<sup>3</sup>, LRA 31.0 A

---

**Mbsm.pro, Compressor,**

# Embraco, Aspera, MA8DCV04, NT6220GK, Hermetic reciprocating compressor , R404a, MHBP, 17.4CC, 3/4Hp, ++big, 240V~50Hz

written by Lilianne | 11 April 2022



Private Picture Copyright: [WWW.MBSM.PRO](http://WWW.MBSM.PRO)

Mbsm.pro, Compressor, Embraco, Aspera, NT6220GK, Hermetic  
reciprocating compressor , R404a, MHBP, 17.4CC, 3/4Hp, ++big,  
240V~50Hz

---

## Mbsm.pro, Compressor, Embraco, Aspera, NEK6214Z,

**HBP, R134a, 220 –  
240V/1/50Hz, 1/2 HP, CSIR,  
HBP, Big ++**

written by Lilianne | 11 April 2022



Private Picture Copyright: WWW.MBSM.PRO

Mbsm.pro, Compressor, Embraco, Aspera, NEK6214Z, HBP, R134a,  
220 – 240V/1/50Hz, 1/2 HP, CSIR, HBP, Big ++

---

**Mbsm.pro, Compressor,  
BP1072Z, 221CA32, 1/10 Hp,  
66W, EMBRACO, ASPERA, r134A,  
Lbp, HERMETIC COMPRESSORS,**

# Oil 200 cc, 220 V/ 60 Hz

written by Lilianne | 11 April 2022



Mbsm.pro, Compressor, BP1072Z, 221CA32, 1/10 Hp, 66W, EMBRACO, ASPERA, r134A, Lbp, HERMETIC COMPRESSORS, Oil 200 cc, 220 V/ 60 Hz

---

**Mbsm.pro, Embraco, Aspera, NEU2155GK, R404A, 220 – 240V 1~ 50 Hz, 3/4 hp , 12.1 cm<sup>3</sup>, R404A, freezing (LBP), csir, 12.12cc**

written by Lilianne | 11 April 2022

Mbsm.pro, Embraco, Aspera, NEU2155GK, R404A, 220 – 240V 1~ 50 Hz, 3/4 hp , 12.1 cm<sup>3</sup>, R404A, freezing (LBP), csir, 12.12cc

---

**Mbsm.pro, Compressor, Embraco, Aspera, EMY26CLC, LBP, R600a, 220 – 240V/1/50Hz, 1/12 HP, RSIR, LRA 7.8 A, 83 Wat**

written by Lilianne | 11 April 2022



Compressor, Embraco, Aspera, EMY26CLC, LBP, R600a, 220 – 240V/1/50Hz, 1/12 HP, RSIR, LRA 7.8 A, 83 Wat

**Mbsm.pro, Compressor,  
EMBRACO, NBM1119Y, Indesit,  
Ariston, ASPERA, R600, 1/3  
HP, 237W, LBP**

written by Lilianne | 11 April 2022

Compressor	EMBRACO
Template	NBM1119Y

<b>Height (mm)</b>	
<b>Gas</b>	R600a
<b>Voltage</b>	200-240V 50Hz / 230V 60Hz
<b>Application</b>	LBP (Low Back Pressure)
<b>Test Condition</b>	ASHRAE LBP 32
<b>Displacement</b>	14.28 of the Italian Civil Code
<b>Motor</b>	RSIR
<b>Power (HP)</b>	
<b>Cap. Frigor. Watt</b>	233
<b>Cap. Frigor. Kcal</b>	200
<b>Cap. Frigor. Btu / h</b>	795
<b>COP (W / W)</b>	1.44
<b>Watt absorbed (W)</b>	
<b>Device of Avv.</b>	PTC
<b>Capacitor</b>	
<b>Cooling type</b>	
<b>Packaging (Pcs / Pallet)</b>	







Private Picture Copyright: WWW.MBSM.PRO

# COMPRESSOR, ASPERA, NJ2192GK, 1.1/4 HP, 220V, 1PH, R404A, LBP, 1199w

written by Lilianne | 11 April 2022

Compressor ASPERA NJ2192GJ | NJ 2192 GJ

Product replaced the old model NJ2192GK


Refrigerant	R404A
Working range[stC] LBP	-40 do -10
Nominal capacity [W] (evaporating temperature -23,3C, Condensing temperatur +54,4C)	1199

Power supply	220-240V 50Hz
Engine type	CSR
Displacement [cm <sup>3</sup> ]	26,10
Weight [kg]	22

Condensing temperature +55 C

Evaporating Temperature	Cooling Capacity +/-5%			Power Consumption +/-5%	Current Consumption +/-5%
	(kcal/h)	(W)	(Btu/h)	(W)	(A)
°C					
-40					
-35					
-30		797		773	4,37
-25		1084		908	4,92
-20		1413		1045	5,49
-15		1784		1181	6,10
-10		2196		1317	6,72

Refrigerant: R404A



Private Picture Copyright: WWW.MBSM.PRO

Mbsm\_dot\_pro\_private\_PDF\_pdf\_NJ219GJTélécharger

---

# All, Aspera, R12, Compressor, 240V~50hZ, EMBRACO, j2170, Compressor Motor, CC 34.37, 1HP

written by Lilianne | 11 April 2022

## Aspera R12 Compressors

All Aspera compressors are developed for quiet operation, high reliability & compact dimensions. All single phase models are supplied with their respective electrical components. The 'J' family come complete with a 1" rotalock threaded spud connection, except those categorised as air conditioning versions, these like all other compressor families are supplied with brazed connections.

### Key Product Features:

Compressor Model	Motor (HP)	Motor Type	Displacement (CC)	Capacity (Watts)	FLC (Amps)	LRA (Amps)	Cooling Type	Weight (kg)	Height (mm)
R12 LPB									
NB1116B	1/3	RSIR	8.0	134	1.1	9.5	S	9.8	187
NB2118B	1/4	CSIR	8.9/	160	0.9	9.3	S	10.4	187
NE2121A	1/4	CSIR	12.0	192	1.8	11.0	F	10.6	200
T2134A	1/2	CSIR	17.4	306	2.4	30.0	F	13.1	191
T2140A	1/2	CSIR	20.4	340	3.0	20.0	F	14.0	221

## Related Products



Private Picture Copyright: [WWW.MBSM.PRO](http://WWW.MBSM.PRO)





Private Picture Copyright: [WWW.MBSM.PRO](http://WWW.MBSM.PRO)



Private Picture Copyright : [WWW.MBSM.PRO](http://WWW.MBSM.PRO)

Mbsm\_dot\_pro\_private\_PDF\_pdf\_j2170a-1Télécharger  
 Mbsm\_dot\_pro\_private\_PDF\_pdf\_j2170a-1-1Télécharger

Codice	Descrizione	HP	Cilindrata	Gas	Volt	Marca
A1116A	Compressore Aspera LBP	1/5	8,00	R12	220	ASPERA
A11RV	Compressore Necchi LBP	1/2	11,11	R502	220	NECCHI
A11V	Compressore Necchi LBP	1/4	11,11	R12	220	NECCHI
A13R	Compressore Necchi LBP	5/8	13,34	R502	220	NECCHI
A13RV	Compressore Necchi LBP	5/8	13/34	R502	220	NECCHI
A13V	Compressore Necchi LBP	1/3	13,35	R12	220	NECCHI

<b>Codice</b>	<b>Descrizione</b>	<b>HP</b>	<b>Cilindrata</b>	<b>Gas</b>	<b>Volt</b>	<b>Marca</b>
A2116A	Compressore Aspera LBP	1/5	8,00	R12	220	ASPERA
A2118A	Compressore Aspera LBP	1/4	8,85	R12	220	ASPERA
A2121A	Compressore Aspera LBP	1/4	12,00	R12	220	ASPERA
A5160A	Compressore Aspera HBP	1/4	8,00	R12	220	ASPERA
A6170A	Compressore Aspera HBP	1/4	8,85	R12	220	ASPERA
A9RV	Compressore Necchi LBP	1/3	9,29	R502	220	NECCHI
AE41ZF11	Compressore Tecumseh	1/4	8,85	R12	220	Tecumseh
AE4450Z	Compressore L'Unitè Hermetique M-HBP	3/8	8,85	R404A	220	L'Unitè Hermetique
AEZ2411Z	Compressore L'Unitè Hermetique LBP	1/3	7,60	R404A	220	L'Unitè Hermetique
AEZ2415Z	Compressore L'Unitè Hermetique LBP	1/3	8,10	R404A	220	L'Unitè Hermetique
AEZ4425Y	Compressore L'Unitè Hermetique M-HBP	1/4	7,55	R134A	220	L'Unitè Hermetique
AEZ4425Z	Compressore L'Unitè Hermetique M-HBP	1/5	4,50	R404A	220	L'Unitè Hermetique
AEZ4430Y	Compressore L'Unitè Hermetique M-HBP	1/4	8,85	R134A	220	L'Unitè Hermetique



<b>Codice</b>	<b>Descrizione</b>	<b>HP</b>	<b>Cilindrata</b>	<b>Gas</b>	<b>Volt</b>	<b>Marca</b>
<b>AEZ4430Z</b>	<b>Compressore L'Unitè Hermetique M-HBP</b>	<b>1/4</b>	<b>5,70</b>	<b>R404A</b>	<b>220</b>	<b>L'Unitè Hermetique</b>
<b>AEZ4440Z</b>	<b>Compressore L'Unitè Hermetique M-HBP</b>	<b>1/3</b>	<b>7,55</b>	<b>R404A</b>	<b>220</b>	<b>L'Unitè Hermetique</b>
<b>AS75AA</b>	<b>Compressore Electrolux LBP</b>	<b>1/5</b>	<b>6,64</b>	<b>R134A</b>	<b>220</b>	<b>ELECTROLUX</b>
<b>B6144GK</b>	<b>Compressore Aspera HBP</b>	<b>1/5</b>	<b>4,39</b>	<b>R404A</b>	<b>220</b>	<b>ASPERA</b>
<b>BP1046Z</b>	<b>Compressore Aspera LBP</b>	<b>1/15</b>	<b>2,85</b>	<b>R134A</b>	<b>220</b>	<b>ASPERA</b>
<b>BP1058Z</b>	<b>Compressore Aspera LBP</b>	<b>1/12</b>	<b>3,44</b>	<b>R134A</b>	<b>220</b>	<b>ASPERA</b>
<b>BP1111Z</b>	<b>Compressore Aspera LBP</b>	<b>1/6</b>	<b>5,93</b>	<b>R134A</b>	<b>220</b>	<b>ASPERA</b>
<b>BP5125H</b>	<b>Compressore Aspera MBP/HBP</b>	<b>1/10</b>	<b>3,40</b>	<b>R134A</b>	<b>220</b>	<b>ASPERA</b>
<b>BP5128H</b>	<b>Compressore Embraco HBP</b>	<b>1/10</b>	<b>4,60</b>	<b>R134A</b>	<b>220</b>	<b>EMBRACO</b>
<b>BPM1072Z</b>	<b>Compressore Embraco LBP</b>		<b>3,43</b>	<b>R134A</b>	<b>220</b>	<b>EMBRACO</b>
<b>CAE2417Z</b>	<b>Compressore L'Unitè Hermetique LBP</b>	<b>3/8</b>	<b>11,30</b>	<b>R404A</b>	<b>220</b>	<b>L'Unitè Hermetique</b>
<b>CAE2420Z</b>	<b>Compressore L'Unitè Hermetique LBP</b>	<b>1/2</b>	<b>12,54</b>	<b>R404A</b>	<b>220</b>	<b>L'Unitè Hermetique</b>
<b>CAE2424Z</b>	<b>Compressore L'Unitè Hermetique LBP</b>	<b>5/8</b>	<b>15</b>	<b>R404A</b>	<b>220</b>	<b>L'Unitè Hermetique</b>

<b>Codice</b>	<b>Descrizione</b>	<b>HP</b>	<b>Cilindrata</b>	<b>Gas</b>	<b>Volt</b>	<b>Marca</b>
CAE4440Y	Compressore L'Unitè Hermetique M-HBP	1/3	12,05	R134A	220	L'Unitè Hermetique
CAE4448Y	Compressore L'Unitè Hermetique M-HBP	3/8	14,15	R134A	220	L'Unitè Hermetique
CAE4450Z	Compressore L'Unitè Hermetique M-HBP	3/8	9,40	R404A	220	L'Unitè Hermetique
CAE4456Y	Compressore L'Unitè Hermetique M-HBP	1/2	16,00	R134A	220	L'Unitè Hermetique
CAE9450Z	Compressore L'Unitè Hermetique M-HBP	3/8	9,40	R404A	220	L'Unitè Hermetique
CAE9460Z	Compressore L'Unitè Hermetique M-HBP	1/2	11,30	R404A	220	L'Unitè Hermetique
CAE9470Z	Compressore L'Unitè Hermetique M-HBP	5/8	13,30	R404A	220	L'Unitè Hermetique
CAJ2428Z	Compressore L'Unitè Hermetique LBP	5/8	15,20	R404A	220	L'Unitè Hermetique
CAJ2432Z	Compressore L'Unitè Hermetique LBP	3/4	18,30	R404A	220	L'Unitè Hermetique

<b>Codice</b>	<b>Descrizione</b>	<b>HP</b>	<b>Cilindrata</b>	<b>Gas</b>	<b>Volt</b>	<b>Marca</b>
CAJ2440Z	Compressore L'Unitè Hermetique LBP	1		R404A	220	L'Unitè Hermetique
CAJ2446Z	Compressore L'Unitè Hermetique LBP	1,2	26,15	R404A	220	L'Unitè Hermetique
CAJ2464Z	Compressore L'Unitè Hermetique LBP	1,7	34,45	R404A	220	L'Unitè Hermetique
CAJ2T12A	Compressore L'Unitè Hermetique LBP	1,2		R404A	220	L'Unitè Hermetique
CAJ4461Y	Compressore L'Unitè Hermetique M-HBP	1/2	18,30	R134A	220	L'Unitè Hermetique
CAJ4476Y	Compressore L'Unitè Hermetique M-HBP	3/4	21,75	R134A	220	L'Unitè Hermetique
CAJ4492Y	Compressore L'Unitè Hermetique M-HBP	3/4	25,95	R134A	220	L'Unitè Hermetique
CAJ4511Y	Compressore L'Unitè Hermetique M-HBP	1	32,70	R134A	220	L'Unitè Hermetique
CAJ4519T	Compressore L'Unitè Hermetique M-HBP	1,5	34,45	R22	220	L'Unitè Hermetique

<b>Codice</b>	<b>Descrizione</b>	<b>HP</b>	<b>Cilindrata</b>	<b>Gas</b>	<b>Volt</b>	<b>Marca</b>
CAJ4519Z	Compressore L'Unitè Hermetique M-HBP	1,5	34,45	R404A	220	L'Unitè Hermetique
CAJ9480Z	Compressore L'Unitè Hermetique M-HBP	5/8		R404A	220	L'Unitè Hermetique
CAJ9510T	Compressore L'Unitè Hermetique M-HBP	3/4	18,30	R22	220	L'Unitè Hermetique
CAJ9510Z	Compressore L'Unitè Hermetique M-HBP	3/4		R404A	220	L'Unitè Hermetique
CAJ9513T	Compressore L'Unitè Hermetique M-HBP	1,1	24,20	R22	220	L'Unitè Hermetique
CAJ9513Z	Compressore L'Unitè Hermetique M-HBP	1,1		R404A	220	L'Unitè Hermetique
CAJ9517Z	Compressore L'Unitè Hermetique M-HBP	1,2		R404A	220	L'Unitè Hermetique
E2121A	Compressore Aspera LBP	1/4	12,00	R12	220	ASPERA
E6187A	Compressore Aspera HBP	1/3	12,00	R12	220	ASPERA
E7213F	Compressore Aspera AC	! /2	12,12	R22	220	ASPERA
E7215F	Compressore Aspera AC	1/2	13,25	R22	220	ASPERA

<b>Codice</b>	<b>Descrizione</b>	<b>HP</b>	<b>Cilindrata</b>	<b>Gas</b>	<b>Volt</b>	<b>Marca</b>
<b>EGL45AA</b>	<b>Compressore Electrolux LBP</b>	<b>1/8</b>	<b>4,56</b>	<b>R134A</b>	<b>220</b>	<b>ELECTROLUX</b>
<b>EGL60AA</b>	<b>Compressore Electrolux LBP</b>	<b>1/6</b>		<b>R134A</b>	<b>220</b>	<b>ELECTROLUX</b>
<b>EGL80AA</b>	<b>Compressore Electrolux LBP</b>	<b>1/5</b>	<b>8,10</b>	<b>R134A</b>	<b>220</b>	<b>ELECTROLUX</b>
<b>EGL80TB</b>	<b>Compressore Electrolux M-HBP</b>	<b>1/5</b>		<b>R134A</b>	<b>220</b>	<b>ELECTROLUX</b>
<b>EGL90AA</b>	<b>Compressore Electrolux LBP</b>	<b>1/4</b>	<b>9,08</b>	<b>R134A</b>	<b>220</b>	<b>ELECTROLUX</b>
<b>EGL90TB</b>	<b>Compressore Electrolux M-HBP</b>	<b>1/4</b>		<b>R134A</b>	<b>220</b>	<b>ELECTROLUX</b>
<b>EGP12FB</b>	<b>Compressore Electrolux LBP</b>	<b>1/3</b>		<b>R134A</b>	<b>220</b>	<b>ELECTROLUX</b>
<b>EGP12TB</b>	<b>Compressore Electrolux M-HBP</b>	<b>3/8</b>		<b>R134A</b>	<b>220</b>	<b>ELECTROLUX</b>
<b>EM60HNP</b>	<b>Compressore Embraco LBP</b>	<b>1/6</b>	<b>5,54</b>	<b>R134A</b>	<b>220</b>	<b>EMBRACO</b>
<b>EMT2117GK</b>	<b>Compressore Embraco LBP</b>	<b>1/4</b>	<b>4,50</b>	<b>R404A</b>	<b>220</b>	<b>EMBRACO</b>
<b>EMT2117U</b>	<b>Compressore Embraco LBP</b>	<b>1/5</b>	<b>3,97</b>	<b>R290</b>	<b>220</b>	<b>EMBRACO</b>
<b>EMT2121GK</b>	<b>Compressore Embraco LBP</b>	<b>1/3</b>	<b>5,19</b>	<b>R404A</b>	<b>220</b>	<b>EMBRACO</b>
<b>EMT2121U</b>	<b>Compressore Embraco LBP</b>	<b>1/4</b>	<b>5,57</b>	<b>R290</b>	<b>220</b>	<b>EMBRACO</b>
<b>EMT2125GK</b>	<b>Compressore Embraco LBP</b>	<b>1/3</b>	<b>5,96</b>	<b>R404A</b>	<b>220</b>	<b>EMBRACO</b>

<b>Codice</b>	<b>Descrizione</b>	<b>HP</b>	<b>Cilindrata</b>	<b>Gas</b>	<b>Volt</b>	<b>Marca</b>
EMT2125U	Compressore Embraco LBP	1/3	5,96	R290	220	EMBRACO
EMT2130U	Compressore Embraco LBP	1/3	6,76	R290	220	EMBRACO
EMT22HLP	Compressore Embraco LBP	1/12	3	R134A	220	EMBRACO
EMT36HLP	Compressore Embraco LBP	1/8	3,97	R134A	220	EMBRACO
EMT37HDP	Compressore Aspera MBP/HBP	1/10	3,30	R134A	220	ASPERA
EMT43HLP	Compressore Embraco LBP	1/6	4,85	R134A	220	EMBRACO
EMT45HDR	Compressore Aspera MBP/HBP	1/8	3,77	R134A	220	ASPERA
EMT49HLP	Compressore Aspera LBP	1/6	6,84	R134A	220	ASPERA
EMT50HDP	Compressore Aspera MBP/HBP	1/6	4,99	R134A	220	ASPERA
EMT60HLP	Compressore Aspera LBP	1/5	7,87	R134A	220	ASPERA
EMT6144GK	Compressore Aspera HBP	1/6	4	R404A	220	ASPERA
EMT6144U	Compressore Embraco HMBP	1/5	4,50	R290	220	EMBRACO
EMT6152U	Compressore Embraco HMBP	1/4	5,20	R290	220	EMBRACO
EMT6160Z	Compressore Embraco HMBP	1/4	6,76	R134A	220	EMBRACO
EMT6165GK	Compressore Aspera HBP	1/5	5,20	R404A	220	ASPERA

<b>Codice</b>	<b>Descrizione</b>	<b>HP</b>	<b>Cilindrata</b>	<b>Gas</b>	<b>Volt</b>	<b>Marca</b>
<b>EMT6165U</b>	<b>Compressore Embraco HMBP</b>	<b>1/4</b>	<b>5,96</b>	<b>R290</b>	<b>220</b>	<b>EMBRACO</b>
<b>EMT6170Z</b>	<b>Compressore Embraco HMBP</b>	<b>1/4</b>	<b>7,69</b>	<b>R134A</b>	<b>220</b>	<b>EMBRACO</b>
<b>EMT6187Z</b>	<b>Compressore Embraco HMBP</b>	<b>1/3</b>	<b>12</b>	<b>R134A</b>	<b>220</b>	<b>EMBRACO</b>
<b>ESM11</b>	<b>Compressore Necchi LBP</b>	<b>1/4</b>	<b>10,63</b>	<b>R12</b>	<b>220</b>	<b>NECCHI</b>
<b>ESM11K</b>	<b>Compressore Necchi LBP</b>	<b>1/4</b>	<b>10,63</b>	<b>R12</b>	<b>220</b>	<b>NECCHI</b>
<b>ESM3.5</b>	<b>Compressore Necchi LBP</b>	<b>1/10</b>	<b>3,50</b>	<b>R12</b>	<b>220</b>	<b>NECCHI</b>
<b>ESM4</b>	<b>Compressore Necchi LBP</b>	<b>1/8</b>	<b>4,10</b>	<b>R12</b>	<b>220</b>	<b>NECCHI</b>
<b>ESM5</b>	<b>Compressore Necchi LBP</b>	<b>1/6</b>	<b>5,11</b>	<b>R12</b>	<b>220</b>	<b>NECCHI</b>
<b>ESM8</b>	<b>Compressore Necchi LBP</b>	<b>1/5</b>	<b>7,75</b>	<b>R12</b>	<b>220</b>	<b>NECCHI</b>
<b>ESM8K</b>	<b>Compressore Necchi LBP</b>	<b>1/5</b>	<b>7,75</b>	<b>R12</b>	<b>220</b>	<b>NECCHI</b>
<b>ESM9</b>	<b>Compressore Necchi LBP</b>	<b>1/4</b>	<b>9,07</b>	<b>R12</b>	<b>220</b>	<b>NECCHI</b>
<b>FR10G</b>	<b>Compressore Danfoss</b>	<b>1/4</b>	<b>9,05</b>	<b>R134A</b>	<b>220</b>	<b>0</b>
<b>FR8 5G</b>	<b>Compressore Danfoss</b>	<b>1/4</b>	<b>7,95</b>	<b>R134A</b>	<b>220</b>	<b>0</b>
<b>GD24AA</b>	<b>Compressore Electrolux LBP</b>	<b>1/20</b>	<b>2,42</b>	<b>R134A</b>	<b>220</b>	<b>ELECTROLUX</b>
<b>GD30MBA</b>	<b>Compressore Electrolux HBP</b>	<b>1/12</b>	<b>3,00</b>	<b>R134A</b>	<b>220</b>	<b>ELECTROLUX</b>

<b>Codice</b>	<b>Descrizione</b>	<b>HP</b>	<b>Cilindrata</b>	<b>Gas</b>	<b>Volt</b>	<b>Marca</b>
<b>GD36AA</b>	<b>Compressore Electrolux LBP</b>	<b>1/12</b>	<b>3,58</b>	<b>R134A</b>	<b>220</b>	<b>ELECTROLUX</b>
<b>GD36MBA</b>	<b>Compressore Electrolux HBP</b>	<b>1/10</b>	<b>3,60</b>	<b>R134A</b>	<b>220</b>	<b>ELECTROLUX</b>
<b>GD40AA</b>	<b>Compressore Electrolux LBP</b>	<b>1/20</b>	<b>4,03</b>	<b>R134A</b>	<b>220</b>	<b>ELECTROLUX</b>
<b>GL45AA</b>	<b>Compressore Electrolux LBP</b>	<b>1/8</b>	<b>4,56</b>	<b>R134A</b>	<b>220</b>	<b>ELECTROLUX</b>
<b>GL45TB</b>	<b>Compressore Electrolux MBP–MHBP</b>	<b>1/6</b>	<b>4,50</b>	<b>R134A</b>	<b>220</b>	<b>ELECTROLUX</b>
<b>GL60TB</b>	<b>Compressore Electrolux MBP–MHBP</b>	<b>1/5</b>	<b>5,70</b>	<b>R134A</b>	<b>220</b>	<b>ELECTROLUX</b>
<b>GL60TG</b>	<b>Compressore HBP</b>	<b>1/5</b>	<b>5,67</b>	<b>R134A</b>	<b>220</b>	<b>ELECTROLUX</b>
<b>GL80AA</b>	<b>Compressore Electrolux LBP</b>	<b>1/5</b>	<b>8,10</b>	<b>R134A</b>	<b>220</b>	<b>ELECTROLUX</b>
<b>GL80TB</b>	<b>Compressore Electrolux MBP–MHBP</b>	<b>1/4</b>	<b>7,60</b>	<b>R134A</b>	<b>220</b>	<b>ELECTROLUX</b>
<b>GL90AA</b>	<b>Compressore Electrolux LBP</b>	<b>1/4</b>	<b>9,08</b>	<b>R134A</b>	<b>220</b>	<b>ELECTROLUX</b>
<b>GL90TB</b>	<b>Compressore Electrolux MBP–MHBP</b>	<b>1/4</b>	<b>8,80</b>	<b>R134A</b>	<b>220</b>	<b>ELECTROLUX</b>
<b>GP12AB</b>	<b>Compressore Electrolux LBP</b>	<b>1/3</b>	<b>12,00</b>	<b>R134A</b>	<b>220</b>	<b>ELECTROLUX</b>
<b>GP12TB</b>	<b>Compressore Electrolux MBP–MHBP</b>	<b>1/3</b>	<b>12,00</b>	<b>R134A</b>	<b>220</b>	<b>ELECTROLUX</b>



<b>Codice</b>	<b>Descrizione</b>	<b>HP</b>	<b>Cilindrata</b>	<b>Gas</b>	<b>Volt</b>	<b>Marca</b>
<b>GP14TB</b>	<b>Compressore Electrolux MBP-MHBP</b>	<b>3/8</b>	<b>14,00</b>	<b>R134A</b>	<b>220</b>	<b>ELECTROLUX</b>
<b>GQR80TG</b>	<b>Compressore</b>	<b>1/4</b>	<b>8,1</b>	<b>R134A</b>	<b>220</b>	
<b>GR18TB-T</b>	<b>Compressore Electrolux MBP-MHBP</b>	<b>1/2</b>	<b>18,12</b>	<b>R134A</b>	<b>220</b>	<b>ELECTROLUX</b>
<b>GR22TB-T</b>	<b>Compressore Electrolux MBP-MHBP</b>	<b>5/8</b>	<b>21,74</b>	<b>R134A</b>	<b>220</b>	<b>ELECTROLUX</b>
<b>GS26TB-T</b>	<b>Compressore Electrolux MBP-MHBP</b>	<b>3/4</b>	<b>25,95</b>	<b>R134A</b>	<b>220</b>	<b>ELECTROLUX</b>
<b>GS30TB-T</b>	<b>Compressore Electrolux MBP-MHBP</b>	<b>3/4</b>	<b>29,93</b>	<b>R134A</b>	<b>220</b>	<b>ELECTROLUX</b>
<b>GS34TB-T</b>	<b>Compressore Electrolux MBP-MHBP</b>	<b>1</b>	<b>34,25</b>	<b>R134A</b>	<b>220</b>	<b>ELECTROLUX</b>
<b>HGA2426Z</b>	<b>Compressore Rotativo Orizzontale L'Unitè Hermetique LBP</b>		<b>9,5</b>	<b>R404</b>	<b>220</b>	
<b>HGA2432Z</b>	<b>Compressore Rotativo Orizzontale L'Unitè Hermetique LBP</b>		<b>11,5</b>	<b>R404</b>	<b>220</b>	
<b>HGA2436Z</b>	<b>Compressore Rotativo Orizzontale L'Unitè Hermetique LBP</b>		<b>12,7</b>	<b>R404</b>	<b>220</b>	

<b>Codice</b>	<b>Descrizione</b>	<b>HP</b>	<b>Cilindrata</b>	<b>Gas</b>	<b>Volt</b>	<b>Marca</b>
HGA2446Z	Compressore Rotativo Orizzontale L'Unitè Hermetique LBP		16,1	R404	220	
HGA4445Y	Compressore Rotativo Orizzontale L'Unitè Hermetique MBP		9,5	R134	220	
HGA4450Y	Compressore Rotativo Orizzontale L'Unitè Hermetique MBP		11,5	R134	220	
HGA4460Y	Compressore Rotativo Orizzontale L'Unitè Hermetique MBP		12,7	R134	220	
HGA4467Z	Compressore Rotativo Orizzontale L'Unitè Hermetique MBP		9,5	R404	220	
HGA4476Y	Compressore Rotativo Orizzontale L'Unitè Hermetique MBP		16,1	R134	220	

<b>Codice</b>	<b>Descrizione</b>	<b>HP</b>	<b>Cilindrata</b>	<b>Gas</b>	<b>Volt</b>	<b>Marca</b>
HGA4480Z	Compressore Rotativo Orizzontale L'Unitè Hermetique MBP		11,5	R404	220	
HGA4492Z	Compressore Rotativo Orizzontale L'Unitè Hermetique MBP		12,7	R404	220	
HGA4512Z	Compressore Rotativo Orizzontale L'Unitè Hermetique MBP		16,1	R404	220	
HMK12AA	Compressore ACC LBP		11,20	R600A	220	
HTK12AA	Compressore ACC LBP		11,14	R600A	220	
J2152A	Compressore Aspera LBP	5/8	26,00	R12	220	ASPERA
J2152M	Compressore Aspera LBP	5/8	26,00	R12	220	ASPERA
J2152Z	Compressore Aspera LBP	3/4	27,12	R134A	220	ASPERA
J2170A	Compressore Aspera LBP	1	34,37	R12	220	ASPERA
J2170M	Compressore Aspera LBP	1	34,37	R12	380	ASPERA
J2178E	Compressore Aspera LBP	1	23,50	R22	220	ASPERA
J2190E	Compressore Aspera LBP	1,2	27,10	R22	220	ASPERA
J2192GK	Compressore Aspera LBP	1,2	26,00	R404A	220	ASPERA

<b>Codice</b>	<b>Descrizione</b>	<b>HP</b>	<b>Cilindrata</b>	<b>Gas</b>	<b>Volt</b>	<b>Marca</b>
J2192GS	Compressore Aspera LBP	1,2	26,00	R404A	380	ASPERA
J2212GK	Compressore Aspera LBP	1,7	34,37	R404A	220	ASPERA
J2212GS	Compressore Aspera LBP	1,7	34,37	R404A	380	ASPERA
J6220A	Compressore Aspera HBP	3/4	25,80	R12	220	ASPERA
J6220Z	Compressore Aspera MBP/HBP	3/4	25,80	R134A	220	ASPERA
J6220ZX	Compressore Aspera MHP/HBP	3/4	25,80	R134A	380	ASPERA
J6226A	Compressore Aspera HBP	1	34,37	R12	220	ASPERA
J6226M	Compressore Aspera HBP	1	34,37	R12	380	ASPERA
J6226Z	Compressore Aspera MBP/HBP	1	34,37	R134A	220	ASPERA
J6226ZX	Compressore Aspera MBP/HBP	1	34,37	R134A	380	ASPERA
J7225F	Compressore Aspera AC	1	21,70	R22	220	ASPERA
J7228F	Compressore Aspera AC	1,1	23,80	R22	220	ASPERA
J7228P	Compressore Aspera AC	1,1	23,80	R22	380	ASPERA
J7231F	Compressore Aspera AC	1,2	26,20	R22	220	ASPERA
J7231P	Compressore Aspera AC	1,2	26,20	R22	380	ASPERA
J7238E	Compressore Aspera AC	1,5	32,65	R22	220	

<b>Codice</b>	<b>Descrizione</b>	<b>HP</b>	<b>Cilindrata</b>	<b>Gas</b>	<b>Volt</b>	<b>Marca</b>
J7238P	Compressore Aspera AC	1,5	32,65	R22	380	
J7240F	Compressore Aspera AC	1,75	34,37	R22	220	
J7240P	Compressore Aspera AC	1,75	34,37	R22	380	
J9226E	Compressore Aspera MBP/HBP	1	21,70	R22	220	
J9226GK	Compressore Aspera HBP	1	21,70	R404A	220	
J9226GS	Compressore Aspera HBP	1	21,70	R404A	380	
J9226P	Compressore Aspera MBP/HBP	1	21,70	R22	380	
J9232E	Compressore Aspera MBP/HBP	1,2	26,20	R22	220	
J9232GK	Compressore Aspera HBP	1,2	26,14	R404A	220	
J9232GS	Compressore Aspera HBP	1,2	26,14	R404A	220	
J9232P	Compressore Aspera MBP/HBP	1,2	26,20	R22	380	
J9238E	Compressore Aspera MBP/HBP	1,5	32,70	R22	220	
J9238GK	Compressore Aspera HBP	1,5	32,70	R404A	220	
J9238GS	Compressore Aspera HBP	1,5	32,70	R404A	380	
J9238P	Compressore Aspera MBP/HBP	1,5	32,70	R22	380	

<b>Codice</b>	<b>Descrizione</b>	<b>HP</b>	<b>Cilindrata</b>	<b>Gas</b>	<b>Volt</b>	<b>Marca</b>
<b>L40TN</b>	<b>Compressore Electrolux MBP-MHBP</b>	<b>1/6</b>	<b>4,04</b>	<b>R22</b>	<b>220</b>	
<b>L45TN</b>	<b>Compressore Electrolux MBP-MHBP</b>	<b>1/5</b>	<b>4,50</b>	<b>R22</b>	<b>220</b>	
<b>L57TN</b>	<b>Compressore Electrolux MBP-MHBP</b>	<b>1/4</b>	<b>5,67</b>	<b>R22</b>	<b>220</b>	
<b>L76TN</b>	<b>Compressore Electrolux MBP-MHBP</b>	<b>1/4</b>	<b>7,57</b>	<b>R22</b>	<b>220</b>	
<b>L88TN</b>	<b>Compressore Electrolux MBP-MHBP</b>	<b>1/3</b>	<b>8,85</b>	<b>R22</b>	<b>220</b>	
<b>MK16TB</b>	<b>Compressore Electrolux MBP-MHBP</b>	<b>3/4</b>	<b>15</b>	<b>R404A-R507-R407B</b>	<b>220</b>	
<b>ML40TB</b>	<b>Compressore Electrolux MBP-MHBP</b>	<b>1/6</b>	<b>4</b>	<b>R404A-R507-R407B</b>	<b>220</b>	
<b>ML45TB</b>	<b>Compressore Electrolux MBP-MHBP</b>	<b>1/5</b>	<b>4,5</b>	<b>R404A-R507-R407B</b>	<b>220</b>	
<b>ML60FB</b>	<b>Compressore Electrolux LBP</b>	<b>1/5</b>	<b>6,00</b>	<b>R404A-R507-R407B</b>	<b>220</b>	
<b>ML60TB</b>	<b>Compressore Electrolux MBP-MHBP</b>	<b>1/4</b>	<b>5,67</b>	<b>R404A-R507-R407B</b>	<b>220</b>	
<b>ML80TB</b>	<b>Compressore Electrolux MBP-MHBP</b>	<b>1/4</b>	<b>7,57</b>	<b>R404A-R507-R407B</b>	<b>220</b>	
<b>ML90FB</b>	<b>Compressore Electrolux LBP</b>	<b>1/4</b>	<b>8,80</b>	<b>R404A-R507-R407B</b>	<b>220</b>	

<b>Codice</b>	<b>Descrizione</b>	<b>HP</b>	<b>Cilindrata</b>	<b>Gas</b>	<b>Volt</b>	<b>Marca</b>
<b>ML90TB</b>	<b>Compressore Electrolux MBP-MHBP</b>	<b>1/3</b>	<b>8,85</b>	<b>R404A-R507-R407B</b>	<b>220</b>	
<b>MP12FB</b>	<b>Compressore Electrolux LBP</b>	<b>1/3</b>	<b>12</b>	<b>R404A-R507-R407B</b>	<b>220</b>	
<b>MP12TB</b>	<b>Compressore Electrolux MBP-MHBP</b>	<b>1/2</b>	<b>12</b>	<b>R404A-R507-R407B</b>	<b>220</b>	
<b>MP14FB</b>	<b>Compressore Electrolux LBP</b>	<b>1/2</b>	<b>14</b>	<b>R404A-R507-R407B</b>	<b>220</b>	
<b>MP14TB</b>	<b>Compressore Electrolux MBP-MHBP</b>	<b>5/8</b>	<b>14</b>	<b>R404A-R507-R407B</b>	<b>220</b>	
<b>MR18FB</b>	<b>Compressore Electrolux LBP</b>	<b>3/4</b>	<b>18,20</b>	<b>R404A-R507-R407B</b>	<b>220</b>	
<b>MR18TB</b>	<b>Compressore Electrolux MBP-MHBP</b>	<b>1</b>	<b>18,12</b>	<b>R404A-R507-R407B</b>	<b>220</b>	
<b>MR22FB-T</b>	<b>Compressore Electrolux LBP</b>	<b>1</b>	<b>21,80</b>	<b>R404A-R507-R407B</b>	<b>220</b>	
<b>MR22TB</b>	<b>Compressore Electrolux MBP-MHBP</b>	<b>1.1</b>	<b>21,74</b>	<b>R404A-R507-R407B</b>	<b>220</b>	
<b>MR26FB-T</b>	<b>Compressore Electrolux LBP</b>	<b>1.2</b>	<b>26,15</b>	<b>R404A-R507-R407B</b>	<b>220</b>	
<b>MS26TB</b>	<b>Compressore Electrolux MBP-MHBP</b>	<b>1.2</b>	<b>25,95</b>	<b>R404A-R507-R407B</b>	<b>220</b>	
<b>MS34FB-T</b>	<b>Compressore Electrolux LBP</b>	<b>1.5</b>	<b>34,25</b>	<b>R404A-R507-R407B</b>	<b>220</b>	
<b>MX21FB</b>	<b>Compressore Cubigel LBP</b>	<b>3/4</b>	<b>20,72</b>	<b>R404A</b>	<b>220</b>	

<b>Codice</b>	<b>Descrizione</b>	<b>HP</b>	<b>Cilindrata</b>	<b>Gas</b>	<b>Volt</b>	<b>Marca</b>
N17RV	Compressore Necchi LBP	3/4	17,52	R502	220	
N17V	Compressore Necchi LBP	1/2	17,52	R12	220	
N21RV	Compressore Necchi LBP	1	20,68	R502	220	
N21V	Compressore Necchi LBP	3/4	20,68	R12	220	
NB1112Z	Compressore Aspera LBP	1/6	6,72	R134A	220	
NB1116Z	Compressore Aspera LBP	1/5	8,38	R134A	220	
NB1118Z	Compressore Aspera LBP	1/4	8,00	R134A	220	
NB2117GK	Compressore Aspera LBP	1/5	4,39	R404A	220	
NB2118Z	Compressore Aspera LBP	1/4	8,00	R134A	220	
NB2121GK	Compressore Aspera LBP	1/4	6,06	R404A	220	
NB5132Z	Compressore Aspera MBP/HBP	1/6	4,85	R134A	220	
NB5144Z	Compressore Aspera MBP/HBP	1/5	5,90	R134A	220	
NB5160Z	Compressore Aspera MBP/HBP	1/4	8,00	R134A	220	
NB5170Z	Compressore Aspera MBP/HBP	1/4	8,85	R134A	220	
NB6144E	Compressore Aspera MBP/HBP	1/5	5,90	R22	220	
NB6144GK	Compressore Aspera HBP	1/5	4,39	R404A	220	



<b>Codice</b>	<b>Descrizione</b>	<b>HP</b>	<b>Cilindrata</b>	<b>Gas</b>	<b>Volt</b>	<b>Marca</b>
NB6144Z	Compressore Aspera MBP/HBP	1/5	5,90	R134A	220	
NB6152E	Compressore Aspera MBP/HBP	1/4	4,85	R22	220	
NB6152GK	Compressore Aspera MBP/HBP	1/4	4,88	R404A	220	
NB6160Z	Compressore Aspera MBP/HBP	1/4	8,00	R134A	220	
NB6165E	Compressore Aspera MBP/HBP	1/4	6,00	R22	220	
NB6165GK	Compressore Aspera HBP	1/4	6,06	R404A	220	
NB6170Z	Compressore Aspera MBP/HBP	1/4	8,85	R134A	220	
NBT1116Y	Compressore Embraco LBP		12,12	R600A	220	
NE1130Z	Compressore Aspera LBP	1/3	12,12	R134A	220	
NE2121Z	Compressore Aspera LBP	1/4	13,60	R134A	220	
NE2125E	Compressore Aspera LBP	1/4	8,90	R22	220	
NE2125GK	Compressore Aspera LBP	1/3	8,90	R404A	220	
NE2130Z	Compressore Aspera LBP	1/3	15,28	R134A	220	
NE2134E	Compressore Aspera LBP	1/2	12,00	R22	220	
NE2134GK	Compressore Aspera LBP	1/2	12,00	R404A	220	

<b>Codice</b>	<b>Descrizione</b>	<b>HP</b>	<b>Cilindrata</b>	<b>Gas</b>	<b>Volt</b>	<b>Marca</b>
NE5187Z	Compressore Aspera MBP/HBP	1/3	12,00	R134A	220	
NE6144GK	Compressore Aspera HBP	1/5	4,39	R404A	220	
NE6181E	Compressore Aspera MBP/HBP	1/3	7,40	R22	220	
NE6181GK	Compressore Aspera HBP	1/3	7,38	R404A	220	
NE6187Z	Compressore Aspera MBP/HBP	1/3	12,00	R134A	220	
NE6210E	Compressore Aspera MBP/HBP	3/8	8,90	R22	220	
NE6210GK	Compressore Aspera HBP	3/8	8,90	R404A	220	
NE6210Z	Compressore Aspera MBP/HBP	1/2	13,60	R134A	220	
NE6217GK	Compressore Aspera HBP	5/8	14,28	R404A	220	
NE9213E	Compressore Aspera MBP/HBP	1/2	12,00	R22	220	
NE9213GK	Compressore Aspera HBP	1/2	12,00	R404A	220	
NEK2116Z	Compressore Embraco LBP	1/5		R404A	220	
NEK2125GK	Compressore Embraco LBP	1/3	6,20	R404A	220	
NEK2125U	Compressore Embraco LBP	1/3	7,28	R290	220	
NEK2130GK	Compressore Embraco LBP	1/2	7,38	R404A	220	

<b>Codice</b>	<b>Descrizione</b>	<b>HP</b>	<b>Cilindrata</b>	<b>Gas</b>	<b>Volt</b>	<b>Marca</b>
NEK2134GK	Compressore Embraco LBP	1/2	8,78	R404A	220	
NEK2134U	Compressore Embraco LBP	1/2	10,00	R290	220	
NEK2140Z	Compressore Embraco LBP	1/2	16,80	R134A	220	
NEK2150GK	Compressore Embraco LBP	5/8	12,12	R404A	220	EMBRACO
NEK2150U	Compressore Embraco LBP	1/2	13,54	R290	220	
NEK2160U	Compressore Embraco LBP	3/4	16,80	R290	220	
NEK2168GK	Compressore Embraco LBP	3/4	14,28	R404A	220	
NEK6144GK	Compressore Aspera HBP	1/5	4,39	R404A	220	
NEK6160Z	Compressore Aspera MBP/HBP	1/4	8,00	R134A	220	
NEK6165GK	Compressore Aspera HBP	1/4	6,06	R404A	220	
NEK6170Y	Compressore Aspera MBP/HBP	1/4	14,28	R600A	220	
NEK6170Z	Compressore Aspera MBP/HBP	1/4	8,85	R134A	220	
NEK6181GK	Compressore Aspera HBP	1/3	7,38	R404A	220	
NEK6181U	Compressore Embraco HMBP	1/3	7,28	R290	220	
NEK6187Z	Compressore Embraco Aspera M- HBP	1/3	10	R134A	220	

<b>Codice</b>	<b>Descrizione</b>	<b>HP</b>	<b>Cilindrata</b>	<b>Gas</b>	<b>Volt</b>	<b>Marca</b>
NEK6210GK	Compressore Embraco HBP	3/8	8,90	R404A	220	
NEK6210U	Compressore Embraco HMBP	3/8	8,78	R290	220	
NEK6212Z	Compressore Embraco MBP-HBP	1/2	14,30	R134A	220	
NEK6213GK	Compressore Embraco HBP	1/2	12,12	R404A	220V	EMBRACO
NEK6213U	Compressore Embraco HMBP	1/2	12,12	R290	220	
NEK6214Z	Compressore Embraco M-HBP	5/8	16,80	R134A	220	
NEK6217GK	Compressore Embraco MBP	5/8	14,28	R404A	220	
NEK6217U	Compressore Embraco HMBP	5/8	14,30	R290	220	
NEU2178GK	Compressore Aspera	1	16,80	R404A	220	0
NJ2152Z	Compressore Aspera LBP	3/4	27,12	R134A	220	
NJ2192GK	Compressore Aspera LBP	1,2	26	R404A	220	
NJ2192GS	Compressore Aspera LBP	1,2	26	R404A	380	
NJ2212GK	Compressore Aspera LBP	1,7	34,37	R404A	220	
NJ6226Z	Compressore Embraco M-HP	1	34,37	R134A	220	
NJ9226GK	Compressore Embraco M-HP	1	21,70	R404A	220	

<b>Codice</b>	<b>Descrizione</b>	<b>HP</b>	<b>Cilindrata</b>	<b>Gas</b>	<b>Volt</b>	<b>Marca</b>
NJ9226GS	Compressore Embraco M-HP	1	21,70	R404A	380	
NJ9232GK	Compressore Embraco HBP	1,2	26,14	R404A	220	
NJ9232GS	Compressore Embraco HBP	1,2	26,14	R404A	380	EMBRACO
NJ9238GK	Compressore Embraco HBP	1,5	32,70	R404A	220	
NJ9238GS	Compressore Embraco HBP	1,5	32,70	R404A	380	
NL7F	Compressore Danfoss LBP	1/5	7,27	R134A	220	
NL8.4MF	Compressore Secop LBP-HBP		8,3	R134A	220	0
NLE11KK4	Compressore Secop LBP		11,15	R600A	220	0
NT2160U	Compressore Embraco LBP	3/4	17,40	R290	220	
NT2168GK	Compressore Embraco LBP	3/4	14,50	R404A	220	
NT2168GS	Compressore Embraco LBP	3/4	14,50	R404A	380	
NT2170U	Compressore Embraco LBP	3/4	20,44	R290	220	
NT2178GK	Compressore Embraco LBP	1	17,40	R404A	220	
NT2180GK	Compressore Embraco LBP	1,1	20,40	R404A	220	
NT2180U	Compressore Embraco LBP	1	22,40	R290	220	
NT2192GK	Compressore Embraco LBP	1,2	22,40	R404A	220	
NT2192GS	Compressore Embraco LBP	1,2	22,40	R404A	380	

<b>Codice</b>	<b>Descrizione</b>	<b>HP</b>	<b>Cilindrata</b>	<b>Gas</b>	<b>Volt</b>	<b>Marca</b>
NT2210U	Compressore Embraco LBP	1 1/4	27,80	R290	220	
NT2212GK	Compressore Embraco LBP	1,7	27,80	R404A	220	
NT2212GS	Compressore Embraco LBP	1,7	27,80	R404A	380	
NT6217U	Compressore Embraco HMBP	5/8	14,50	R290	220	
NT6220GK	Compressore Embraco HBP	3/4	14,50	R404A	220	
NT6220U	Compressore Embraco HMBP	3/4	17,40	R290	220	
NT6222GK	Compressore Embraco HBP	1	17,40	R404A	220	
NT6222U	Compressore Embraco HMBP	1	20,44	R290	220	
NT6224U	Compressore Embraco HMBP	1 1/4	17,40	R290	220	
NT6226GK	Compressore Embraco HBP	1	22,40	R404A	220	
OF1033A	Compressore ACC LBP		5,73	R134A	220	
P12TN	Compressore Electrolux MBP-MHBP	1/2	12	R22	220	
R18TN	Compressore Electrolux MBP-MHBP	7/8	18,12	R22	220	
R18TN-T	Compressore Electrolux MBP-MHBP	3/4	18,12	R22	220	

<b>Codice</b>	<b>Descrizione</b>	<b>HP</b>	<b>Cilindrata</b>	<b>Gas</b>	<b>Volt</b>	<b>Marca</b>
S19UN	Compressore Electrolux AC	7/8	18,64	R22	220	
S22TN	Compressore Electrolux MBP-MHBP	7/8	21,78	R22	220	
S22TN-T	Compressore Electrolux MBP-MHBP	1	21,78	R22	220	
S26TN	Compressore Electrolux MBP-MHBP	1,1/4	25,95	R22	220	
S26TN-T	Compressore Electrolux MBP-MHBP	1,1	25,95	R22	220	
SC15G	Compressore Secop	3/8	15,28	R134A	220	0
SC18CL	Compressore Danfoss LBP	1	17,69	R404A	220	DANFOSS
SC21CL	Compressore Danfoss LBP	1.1	20,95	R404A	220	DANFOSS
T2124A	Compressore Aspera LBP	1/4	12,58	R12	220	
T2128A	Compressore Aspera LBP	1/3	14,50	R12	220	
T2134A	Compressore Aspera LBP	1/2	17,40	R12	220	
T2134Z	Compressore Aspera LBP	1/2	19,04	R134A	220	
T2140A	Compressore Aspera LBP	1/2	20,40	R12	220	
T2140E	Compressore Aspera LBP	1/2	14,50	R22	220	
T2140GK	Compressore Aspera LBP	1/2	12,58	R404A	220	
T2140Z	Compressore Aspera LBP	1/2	22,40	R134A	220	

<b>Codice</b>	<b>Descrizione</b>	<b>HP</b>	<b>Cilindrata</b>	<b>Gas</b>	<b>Volt</b>	<b>Marca</b>
T2155E	Compressore Aspera LBP	5/8	17,40	R22	220	
T2155GK	Compressore Aspera LBP	5/8	14,50	R404A	220	
T2168E	Compressore Aspera LBP	3/4	20,40	R22	220	
T2168GK	Compressore Aspera LBP	3/4	17,40	R404A	220	
T2178GK	Compressore Aspera LBP	1	20,40	R404A	220	
T6185A	Compressore Aspera HBP	1/3	12,58	R12	220	
T6213A	Compressore Aspera HBP	1/2	17,40	R12	220	
T6213Z	Compressore Aspera MBP/HBP	1/2	17,40	R134A	220	
T6215A	Compressore Aspera HBP	1/2	20,40	R12	220	
T6215Z	Compressore Aspera MBP/HBP	5/8	20,40	R134A	220	
T6217E	Compressore Aspera MBP/HBP	5/8	14,50	R22	220	
T6217GK	Compressore Embraco HBP	5/8	14,51	R404A	220	
T6217Z	Compressore Aspera MBP/HBP	5/8	22,40	R134A	220	
T6220E	Compressore Aspera MBP/HBP	3/4	17,40	R22	220	
T6220GK	Compressore Aspera HBP	3/4	17,40	R404A	220	
T6222GK	Compressore Aspera HBP	1	20,40	R404A	220	



<b>Codice</b>	<b>Descrizione</b>	<b>HP</b>	<b>Cilindrata</b>	<b>Gas</b>	<b>Volt</b>	<b>Marca</b>
T7220E	Compressore Aspera AC	3/4	17,40	R22	220	
T7223E	Compressore Aspera AC	1	20,40	R22	220	
TAJ2428Z	Compressore L'Unitè Hermetique LBP	5/8	15,20	R404A	380	
TAJ2446Z	Compressore L'Unitè Hermetique LBP	1,2	26,15	R404A	380	
TAJ2464Z	Compressore L'Unitè Hermetique LBP	1,7	34,45	R404A	380	
TAJ4461Y	Compressore L'Unitè Hermetique M-HBP	1/2	18,30	R134A	380	
TAJ4492Y	Compressore L'Unitè Hermetique M-HBP	3/4	25,95	R134A	380	
TAJ4511Y	Compressore L'Unitè Hermetique M-HBP	1	32,70	R134A	380	
TAJ4517T	Compressore L'Unitè Hermetique M-HBP	1,2	25,95	R22	380	
TAJ4517Z	Compressore L'Unitè Hermetique M-HBP	1,2	25,95	R404A	380	

<b>Codice</b>	<b>Descrizione</b>	<b>HP</b>	<b>Cilindrata</b>	<b>Gas</b>	<b>Volt</b>	<b>Marca</b>
TAJ4519T	Compressore L'Unitè Hermetique M-HBP	1,5	34,45	R22	380	
TAJ4519Z	Compressore L'Unitè Hermetique M-HBP	1,5	34,45	R404A	380	
TAJ5515E	Compressore L'Unitè Hermetique M-HBP		25,95	R22	380	
TAJ9480T	Compressore L'Unitè Hermetique M-HBP	5/8	15,20	R22	380	
TAJ9480Z	Compressore L'Unitè Hermetique M-HBP	5/8	15,20	R404A	380	
TAJ9510T	Compressore L'Unitè Hermetique M-HBP	3/4	18,30	R22	380	
TAJ9510Z	Compressore L'Unitè Hermetique M-HBP	3/4	18,30	R404A	380	
TAJ9513T	Compressore L'Unitè Hermetique M-HBP	1/1	24,20	R22	380	
TAJ9513Z	Compressore L'Unitè Hermetique M-HBP	1/1	24,20	R404A	380	
TL4DL	Compressore Danfoss HBP	1/5	3,86	R404A	220	

<b>Codice</b>	<b>Descrizione</b>	<b>HP</b>	<b>Cilindrata</b>	<b>Gas</b>	<b>Volt</b>	<b>Marca</b>
<b>TL4F</b>	<b>Compressore Danfoss LBP</b>		<b>3,86</b>	<b>R134A</b>	<b>220</b>	
<b>TL5G</b>	<b>Compressore Danfoss LBP-HBP</b>		<b>5,08</b>	<b>R134A</b>	<b>220</b>	
<b>ZBS1114CY</b>	<b>Compressore Aspera</b>	<b>1/5</b>	<b>11,20</b>	<b>R600A</b>	<b>220</b>	<b>0</b>